## Packet Header Information

**Antenna** 

No of

Channel

**Packet** 

Order

**RCS** 

App

RCS

Lib

Error

**Flags** 

Reserved

No of

64 bits	64 bits	32 bits	32 bits	32 bits	32 bits	16 bits	16 bits	16 bits	32 bits	32 bits	64 bits	128-16-16	
	Total 512 bits												
<ul> <li>Packet Counter: Start from zero after reset</li> <li>Timestamp: 400MHz clock counter. Start from zero after reset.</li> <li>Epoch Second: Second to Epoch Unix time. Transfer from PC</li> <li>PPS Count: 1pps pulse. Start from zero after</li> <li>Local IP: IP if this FPGA 100G Ethernet. Read and write by PC.</li> <li>Destination IP:</li> <li>No. of Antenna: Total antenna of the system</li> </ul>													

Packet Order: Order no. If a spectrum divided by 8 packets, this number will be 0 -7.

**Packet** 

Counter

Time

stamp

**Epoch** 

Second

**PPS** 

Count

No. of Channel: Total channel of the spectrum.

RCS App and RCS Lib: Bitcode version control.

Error Flags: For Overflow and Underflow flags.

Local

IP

**Destination** 

IP